

Tools: hex key 5 and 3 + wrench 8 and 10

Included: 12 bolts + 12 nuts (and rounds)



Make sure you install these parts on the right spot!

Below the saddle of Veloe Multi

Rear of Veloe Multi

1. Mount the holders.

Screw 4 bolts with nut (and rounds on both sides). Use a hex key 5 and a wrench 10 to hold the nut.

Do not tighten yet! You'll have to move the holders when fixing the bars.



2. Push the bars into the holders.

Make sure that the holes equally fit. Be carefull and push a little alternately. If needed, use a soft hammer.

3. Tighten all 4 bolts on the bars.

... and tighten all bolts and nuts at the holders.

Feel that the Rear Child Basket doesn't move and feels solid.

